HUIJUE GROUP

How to Size an MPPT Charge Controller for a Telecom Solar System

Calculate MPPT input voltage, PV short-circuit current and output current for a telecom solar system, then verify battery, thermal and site limits.

Powered by The Solar Telecom

PRODUCT KNOWLEDGE

How to Size an MPPT Charge Controller for a Telecom Solar System

Calculate the PV voltage window, input current and controller output current, then verify battery limits, environmental derating and source coordination.

Updated August 17, 2026MPPT calculation guideApprox. 17 minute read

Contents

Five sizing checks
Required input data
Series and parallel calculation
Controller output current
Worked telecom example
PV array oversizing
One controller or several?
Battery and bus coordination
Verification record

An MPPT controller can have enough wattage on paper and still be the wrong controller. Cold weather may push string open-circuit voltage beyond its PV input limit; hot modules may pull operating voltage below its tracking range; parallel strings may exceed its permitted input current; or the converted output may exceed the controller or battery charge limit.

Reliable **MPPT controller sizing** treats those as separate checks. The controller passes only when the complete PV string arrangement remains inside its voltage and current limits, its output is adequate after environmental derating, and its charge settings are compatible with the battery and telecom power bus.

Electrical safety boundary. PV strings can remain energized whenever illuminated. Calculations, isolation, testing and commissioning must follow the approved project procedure and be performed by qualified personnel using equipment rated for the available DC voltage and fault current.

How do you size an MPPT charge controller for a telecom solar system?

Size the MPPT charge controller by passing five independent checks: cold string Voc, hot string Vmp, qualified PV input current, maximum controller output current and battery/system compatibility. Controller wattage alone cannot replace any of these

checks.

1. Confirm that temperature-corrected maximum string Voc stays below the controller’s absolute PV input voltage and the ratings of associated DC equipment.
2. Confirm that temperature-corrected minimum string Vmp remains inside the tracking range and above the output voltage by the headroom required by the selected controller.
3. Confirm that array Isc, including applicable module, bifacial and design factors, stays within the controller’s permitted PV short-circuit or input-current limit.
4. Calculate the maximum output current at the lowest relevant charging or bus voltage and apply the controller’s temperature and altitude derating.
5. Coordinate charge voltage and current with the battery/BMS, other charging sources, telecom load, protection, cables, cabinet thermal design and monitoring interface.

The Telecom Solar Power Systems guide owns the wider architecture decision. The telecom solar and battery sizing guide determines how much PV energy and storage the site needs. This page begins after the preliminary array power has been established and asks whether a particular controller and string layout can carry it.

Build the input worksheet before calculating

Use values from the exact PV module, controller, battery and site design—not nominal family labels. Record the source document and revision beside each value so a module or controller substitution triggers a new calculation.

Input group	Values required	Why the value matters
PV module at STC	Pmax, Voc, Vmp, Isc, Imp, positive tolerances and maximum series-fuse information	Defines the starting voltage, current and power of each series/parallel arrangement
PV temperature behaviour	Voc coefficient, Vmp coefficient or approved model data, and any bifacial current contribution	Converts STC values to the cold open-circuit and hot operating cases
Site temperature	Record/design minimum temperature and justified maximum cell temperature	Cold increases Voc; hot generally reduces operating voltage
Controller PV input	Absolute maximum Voc, operating/MPPT window, start voltage, maximum PV Isc/input current and input power rules	Sets the permissible series and parallel boundaries
Controller output	Supported output/battery voltage range, continuous output current, current-limit behaviour and derating curves	Determines converted current capacity in the actual cabinet environment

Input group	Values required	Why the value matters
Battery and bus	Minimum/maximum operating voltage, permitted charge voltage/current, BMS interface and other source limits	Prevents a valid PV calculation from violating the storage or telecom interface
Site integration	Load profile, cable lengths, protection, cabinet temperature, altitude, source coordination and redundancy target	Connects the controller rating to conductor, thermal, control and availability decisions

NREL’s Solar Photovoltaic DC Systems paper explains why record-low temperature, module Voc and the module temperature coefficient govern maximum series-string voltage. It also notes that manufacturer coefficients are preferable to generic correction values when they are available.

Do not substitute the power temperature coefficient for the Voc coefficient. They describe different electrical quantities. Likewise, ambient temperature and cell temperature are not interchangeable in the hot operating case; irradiance, mounting and wind can make an illuminated module much hotter than the surrounding air.

How many PV modules can be connected in series and parallel?

Series quantity is bounded by cold Voc at the upper end and hot Vmp at the lower end; parallel quantity is bounded by qualified input current, controller power rules and the array/protection design. Choose only integer combinations that pass all boundaries together.

Cold string open-circuit voltage$V_{oc,cold} = N_s \times V_{oc,STC} \times [1 + \beta_{Voc} \times (T_{min} - 25°C)]$Ns is modules in series. βVoc is entered as a decimal per °C; a datasheet value of −0.28%/°C becomes −0.0028/°C. Add any tolerance or design factor required by the module data, controller manufacturer, project standard and jurisdiction.

The calculated **cold string voltage** must remain below the lowest applicable voltage rating in the PV path, including the controller, disconnects, protective devices, connectors and measurement equipment. Do not treat the controller’s absolute maximum as a normal operating target; use the design allowance required by the selected equipment and project rules.

Hot string maximum-power voltage$V_{mp,hot} = N_s \times V_{mp,STC} \times [1 + \beta_{Vmp} \times (T_{cell,max} - 25°C)]$Use an approved module model or manufacturer sizing tool when βVmp is not supplied. The result must satisfy the controller’s operating window and its required voltage headroom above the maximum output/charge voltage.

A string can pass the cold Voc check and still fail to charge reliably when hot. Many MPPT products used in battery systems are step-down converters: the PV operating voltage must remain sufficiently above the battery or bus voltage. The exact start and tracking headroom belongs to the selected controller manual, not to a universal rule.

Raw array current $I_{sc,array} = N_p \times I_{sc,module}$

$I_{mp,array} = N_p \times I_{mp,module}$ N_p is the number of parallel strings. Apply the current adjustment method required for module tolerance, bifacial gain, expected conditions and the governing electrical standard before comparing the result with equipment and conductor limits.

IEC 62548-1:2023 covers PV array DC wiring, protection, switching and earthing, including systems with DC-to-DC conditioning units. Its scope stops before the storage and load distribution system, so an MPPT input check does not complete the battery-side or telecom-side design.

What output-current rating does the MPPT controller need?

The controller output-current rating must exceed the qualified maximum converted current after applicable derating, while the configured charge limit must remain acceptable to the battery and common bus. Use the lowest output voltage at which full PV power can be delivered because the same power produces more current at lower voltage.

Conservative screening current $I_{out,screen} = P_{array,qualified} \div V_{out,min}$ $P_{array,qualified}$ includes the array power basis required by the selected controller method. This screening equation does not take credit for conversion losses to reduce the required rating. The manufacturer selection tool, allowed PV input power and current-limit behaviour still govern the final result.

The **controller output current** is not automatically the battery charge current. On a common DC bus, part of the controller output can feed the live telecom load while the balance charges storage. If the load falls or another rectifier remains active, battery current changes; the site controller must keep the sum of charging sources within BMS and battery limits.

Check thermal and altitude curves after the nameplate calculation. A controller installed in a sun-heated outdoor cabinet may not deliver its nominal current continuously. As one vendor-specific example, a current Victron SmartSolar manual states different full-output temperature and altitude boundaries for that product family. Those values must not be transferred to a Huijue configuration or another controller.

Output conductors, terminals, fuses or breakers and disconnects are sized from their

own continuous-current, temperature, installation and code requirements. Selecting a 100 A controller does not by itself approve every 100 A cable or protective device.

Worked screening example for a telecom site

The following values are hypothetical. They demonstrate the calculation sequence and do not describe a Huijue model, a standard system voltage or a released project.

Assumed input	Value
PV module Pmax / Voc / Vmp	450 W / 49.5 V / 41.5 V at STC
PV module Isc / Imp	11.6 A / 10.85 A at STC
Temperature coefficients	βVoc = −0.28%/°C; βVmp = −0.30%/°C
Array arrangement	3 modules in series × 3 parallel strings = 9 modules
Design temperatures for screening	Minimum module temperature −15°C; maximum cell temperature 70°C
Candidate controller	200 V absolute PV maximum; 65–180 V tracking window; 50 A maximum PV Isc; 80 A continuous output
Output/battery screening values	50.0 V minimum full-power output case; 57.6 V maximum charge target; 90 A maximum permitted battery charge current

1. Array power

$P_{array} = 9 \times 450\ W = 4{,}050\ W$

2. Cold open-circuit voltage

$V_{oc,cold} = 3 \times 49.5 \times [1 + (-0.0028 \times (-15 - 25))]$
$V_{oc,cold} = 165.1\ V$

The 165.1 V screening result is below the candidate’s 200 V absolute maximum. The designer must still add the specified module/controller/project allowance, confirm the temperature basis and verify every other device in the PV path before declaring the voltage check passed.

3. Hot operating voltage

$V_{mp,hot} = 3 \times 41.5 \times [1 + (-0.0030 \times (70 - 25))]$
$V_{mp,hot} = 107.7\ V$

The calculated 107.7 V is inside the assumed 65–180 V tracking window and above the assumed 57.6 V maximum output target. Final selection must also confirm the

controller’s start/restart behaviour and required headroom at low irradiance.

4. PV input current

Isc,array = 3 × 11.6 A = 34.8 A
Imp,array = 3 × 10.85 A = 32.55 A

The raw 34.8 A Isc is below the assumed 50 A controller limit. This is not yet the final qualified current: module tolerance, bifacial contribution where applicable, design conditions and governing-code factors must be applied and checked against the controller manual and protection design.

5. Output current

Iout,screen = 4,050 W ÷ 50.0 V = 81.0 A

The 80 A candidate does not pass the conservative output-current screen. The design could move to an appropriately rated larger controller, divide the array between coordinated controllers, or use manufacturer-approved clipping if the project’s energy and recovery model accepts it. Even if a 100 A controller is selected, its battery charge limit would need coordination with the assumed 90 A battery limit and every other active charging source.

Sensitivity	Recalculated result	Decision affected
Minimum temperature falls from −15°C to −25°C	Cold string Voc rises from 165.1 V to 169.3 V	Upper PV voltage margin becomes smaller
Maximum cell temperature rises from 70°C to 80°C	Hot string Vmp falls from 107.7 V to 104.0 V	Lower tracking/headroom margin becomes smaller
Minimum full-power output falls from 50.0 V to 48.0 V	Screening output current rises from 81.0 A to 84.4 A	Controller, conductor and protection current increase

This sensitivity table is why a nominal voltage label is insufficient. Use the permitted operating window of the actual battery, telecom load and controller rather than assuming that all communication sites have one fixed DC voltage.

Can the PV array be larger than the MPPT controller’s nominal power?

Only when the controller manufacturer explicitly permits that array size and the design still satisfies maximum Voc, PV Isc/input-current, thermal and operating-window limits. Allowed clipping is a product capability, not a general property that can be assumed for every MPPT controller.

Planned **PV array oversizing** can increase low-irradiance harvest and improve recovery after a low-solar period, but it also increases the time the controller may operate at current limit. The trade-off should be evaluated with the site's time-series energy model, battery recovery requirement, cabinet temperature and measured value of clipped energy.

A Morningstar MPPT technical paper allows oversizing for specific product families while requiring temperature-corrected minimum Vmp and maximum Voc checks. Its percentages and current-limiting behaviour are vendor-specific. A current Victron manual likewise instructs users to keep PV Voc within the selected charger's maximum and to use its model-specific sizing calculator.

Do not assume output current limiting protects the input from excessive voltage. A controller can clip output power and still be damaged if cold Voc or permitted PV short-circuit current is exceeded. Record the manufacturer-approved array power and string configuration for the exact model and software/firmware context.

Should a telecom site use one large MPPT controller or several smaller controllers?

Use one controller when the array is electrically uniform and the single-device failure/maintenance consequence is acceptable; use several when independent orientations, shading zones, current limits, expansion stages or availability requirements justify separate trackers and fault domains.

Decision factor	One larger controller	Several controllers
Electrical layout	Suits one consistent array orientation and string family	Can separate incompatible orientations, module groups or shading patterns
Failure consequence	One controller outage removes all connected PV conversion	A fault may remove only the affected sub-array if protection and bus design isolate it
Installation	Fewer devices, communications links and output branches	More wiring and coordination, but potentially shorter PV runs or phased expansion
Service	Fewer settings and spares, but replacement may be larger and less available locally	Common smaller modules may simplify spares; settings and firmware must remain consistent
Control	One output limit and alarm source	Requires current sharing, source identification, alarm mapping and coordinated battery limits

Multiple controllers do not automatically create redundancy. They must have independent PV inputs, protected output branches and a bus/control arrangement that keeps the remaining controller stable after one unit is isolated. A shared upstream or

downstream component can remain the single point of failure.

Coordinate the controller with the telecom bus and battery

A selected **telecom solar controller** has to operate as part of the site’s power plant. Confirm output polarity and voltage range, rectifier coexistence, battery charge profile, BMS commands, load-disconnect policy, current sharing, source priority, alarm mapping and the fallback state after communication loss.

ITU-T L.1211 (12/2025) addresses smart PV control for base-station sites, including DC power architecture, voltage tracking and PV fault diagnosis. It supports treating the controller as part of an observable system rather than a standalone charger; project settings and interface details still require agreement.

For lithium storage, determine which device owns the final charge-voltage and charge-current limit. The BMS may request derating or inhibit charge at a temperature or cell limit. The MPPT controller must respond in a defined way if that command or communication link is lost. Use the telecom lithium battery guide for battery-duty and BMS selection; do not copy one chemistry’s charging profile into another.

IEC 62509:2010 specifies functioning and performance requirements for terrestrial PV battery charge controllers used with lead-acid batteries. Its scope is useful evidence for that application but should not be presented as a universal acceptance standard for lithium storage or the integrated telecom site.

Turn the calculation into a verification record

The approved calculation should travel with the exact module schedule, controller model, battery interface and settings file. A substitution is not “equal” until the cold/hot voltage, current, power, thermal and control checks have been repeated.

1. **Before procurement:** freeze module/controller datasheets, string schedule, temperatures, coefficient method, voltage/current calculations, derating curves, allowed oversizing and battery limits.
2. **During factory integration:** verify model and firmware, terminal and conductor ratings, branch protection, polarity controls, current limits, charge profile, BMS/EMS communications, alarm points and cabinet thermal assumptions.
3. **At site before energization:** inspect string count and polarity, compare measured open-circuit voltage with the temperature-adjusted expectation, verify approved isolation/protection and record torque and cable identification under the project’s safe procedure.
4. **During commissioning:** trend PV voltage/current, controller output, bus

voltage, battery current, load current, temperature, limiting state and alarms through start-up, charging, source transfer and communication-loss tests.

5. **After handover:** retain maximum observed PV voltage, time at current limit, thermal derating events, daily yield, availability and fault history so the design assumptions can be checked against operation.

Do not test overvoltage by intentionally exceeding the controller rating. Validate protective and alarm behaviour using the manufacturer's approved method or a safe simulated signal where the design supports it. Record instruments, calibration status, environmental conditions and acceptance criteria.

The Morningstar string calculator illustrates the value of using battery limits, site temperatures, module data and controller data together. Use the sizing tool provided for the controller actually selected, and preserve its input assumptions and output rather than keeping only a "pass" screenshot.

Standards and technical references

- IEC 62548-1:2023 — PV array wiring, protection, switching, earthing and DC-to-DC conditioning provisions.
- IEC 62509:2010 — functioning and performance of PV battery charge controllers in its stated lead-acid scope.
- NREL: Solar Photovoltaic DC Systems — temperature-dependent string-voltage design considerations.
- ITU-T L.1211 (12/2025) — smart PV control and fault diagnosis for base-station sites.
- Morningstar MPPT sizing paper and Victron SmartSolar manual — vendor-specific operating-window, input-limit and oversizing examples.

Check the applicable edition, local electrical rules, operator specification and exact product manual at design release. The formulas in this guide are engineering screens; final equipment selection remains configuration-specific.

Send the string calculation, not only the array wattage

Provide Huijue with the module datasheet, series/parallel schedule, site temperature basis, preliminary PV power, battery/bus voltage window, maximum charge current, cabinet environment, altitude, other charging sources, communication requirements and redundancy target. Our engineering team can review the MPPT boundary as part of the integrated telecom energy configuration.

Request an MPPT configuration review

Related engineering resources

Telecom Solar Power Systems
Telecom Solar and Battery Sizing
Lithium Batteries for Telecom Sites
Telecom Energy Monitoring KPIs

Contact Us

For catalog requests, pricing, or partnerships, please visit:
https://www.thesolartelecom.com

How to Size an MPPT Charge Controller for a Telecom Solar System