HUIJUE GROUP

Telecom Battery Backup Time Calculation: Load, DoD, Temperature and Aging

Calculate telecom battery backup time from measured load, usable DoD, path efficiency, minimum temperature, aging allowance and verified discharge data.

PRODUCT KNOWLEDGE

Telecom Battery Backup Time Calculation: Load, DoD, Temperature and Aging

Calculate installed battery energy from the outage load profile, usable state-of-charge window, path efficiency, minimum temperature, end-of-life capacity and recovery duty.

Updated August 26, 2026Battery capacity calculationApprox. 13 minute read

Contents

Screening equation
Backup load
Capacity factors
Worked example
Ampere-hours
Power and voltage
Recharge check
Validation

Project calculation 12 kWh divided by a 3 kW load equals four hours. The arithmetic is correct, but the result is not yet a telecom autonomy guarantee. Nameplate energy may include charge that the controller will not release, capacity unavailable at the design temperature, capacity lost by end of life, and energy consumed before it reaches the critical load.

A defensible **battery backup time** calculation starts with the load energy required during the declared outage and works backward to installed capacity. It then checks whether the proposed modules can deliver the required power without crossing the load’s minimum voltage or the battery’s current and protection limits.

> Energy establishes the first capacity screen. Manufacturer discharge data, the complete DC voltage window and a measured duty test decide whether the selected battery can actually meet it.

How is telecom battery backup time calculated?

For an initial screen, integrate the backed-up load over the autonomy period, then divide that energy by the path efficiency, usable state-of-charge window, minimum-temperature capacity factor and end-of-life capacity factor. Apply any justified design uncertainty once, as a separate numerator factor.

$E_{load} = \Sigma(P_i \times \Delta t_i)$

$E_{nominal,required} = (E_{load} \times f_{margin}) \div (\eta_{path} \times f_{window} \times f_{temperature} \times f_{EOL})$

$\text{Estimated runtime} = (E_{nominal,installed} \times \eta_{path} \times f_{window} \times f_{temperature} \times f_{EOL}) \div P_{load}$

Use kilowatts for P, hours for time and kilowatt-hours for energy. For a constant load, the first equation reduces to $E_{load} = P_{load} \times t$. For a changing load, divide the outage into intervals and sum the energy. Keep every correction factor dimensionless between 0 and 1, except f_{margin}, which is 1 or greater.

Term	Meaning	Evidence required
E_{load}	Energy delivered to all loads that remain active during the defined outage	Interval measurements or an approved mode-based load schedule
η_{path}	Efficiency between battery terminals and the declared load boundary	Cable, protection and conversion losses at the relevant power and voltage
f_{window}	Permitted starting SoC minus the protected stopping SoC, expressed as a fraction	Reserve policy, controller settings and product operating limits
$f_{temperature}$	Fraction of reference capacity available at the minimum design cell temperature	Released discharge data at the required duration and cut-off
f_{EOL}	Specified capacity fraction at the replacement or end-of-life criterion	Approved design criterion, warranty boundary and capacity-test method
f_{margin}	Explicit allowance for quantified load uncertainty or near-term growth	Growth forecast and the uncertainty the factor is intended to cover

ETSI EN 302 099 V2.2.1 treats telecom/ICT backup as a constant-power duty, requires ageing and minimum-temperature effects to be considered, and directs the designer to manufacturer tables or sizing tools. Its Annex B is written for access-network applications, so use the method as relevant guidance and define the actual autonomy from the operator’s service requirement.

Which load should be used in the battery calculation?

Use the maximum credible time-based load that the battery is required to support, measured or modelled at a clearly stated electrical boundary. Include only equipment that remains energized in each outage stage, but include its real conversion, distribution

and environmental support burden.

Good **telecom battery sizing** therefore begins with an operating-mode schedule, not a rectifier-shelf nameplate. A base station can change power with traffic, carrier activation, radio configuration, cooling state and load shedding. Shared sites also add or remove tenant loads on different dates. Use interval data from a representative period and reconcile it with equipment inventories so an inactive meter channel is not mistaken for spare capacity.

Load block	Question for the outage model	Common error
Radio, baseband and transport	What power is required at the declared traffic and network configuration?	Using the quiet-hour average for a daytime outage
Cooling or heating	Which thermal equipment remains active, cycles, starts later or sheds?	Excluding a backed-up fan, heater or DC air conditioner
Security, monitoring and lighting	Which cameras, controllers, routers and safety loads are continuity-critical?	Calling every auxiliary negligible without measurement
Conversion and distribution	Are inverter, DC/DC, cable and protective-device losses already inside the measurement boundary?	Applying an efficiency factor after losses have already been measured
Future tenants or carriers	Which committed additions must be supported within the battery design life?	Adding a generic margin with no expansion schedule

Define load shedding in the same schedule. If the site carries 2.4 kW for the first 30 minutes and then sheds a 0.6 kW auxiliary, the energy calculation should use two intervals rather than four hours at either extreme. The grid-outage operating-sequence guide owns the trigger and recovery logic; this page converts the approved sequence into an energy duty.

For solar-cycling or fully off-grid sites, autonomy is only one part of an hourly energy balance. Use the telecom solar-system sizing workflow to model seasonal generation and repeated charge-discharge cycles. The screening equation here is intended for a defined backup event.

How do DoD, temperature and aging change required capacity?

They reduce the fraction of nameplate energy available to the protected load. A smaller usable SoC window, lower cold-temperature capacity or lower end-of-life capacity therefore increases the installed energy needed for the same load and autonomy.

Usable battery energy should be based on the permitted starting and stopping states,

not a chemistry-wide depth-of-discharge rule. If the battery normally starts an outage at 90% SoC and the controller protects 20% as the floor, f_{window} is 0.70 before considering other factors. A commercial peak-shaving function must not consume the emergency reserve assumed by the calculation.

The **temperature derating factor** should come from product discharge data at the lowest credible cell temperature, required power or rate, discharge duration and end voltage. Cold conditions can reduce immediately available capacity and permitted current. High temperature may not reduce short-duration energy in the same way, but it can accelerate ageing and impose BMS or thermal limits; do not replace those two effects with one guessed percentage.

A **battery aging factor** represents the capacity the system must still deliver at its specified replacement point. An 80% end-of-life criterion is common in some stationary practices and appears as general guidance in ETSI EN 302 099, but it is not a universal value for every chemistry, warranty or operator. State the criterion and how it will be verified.

ITU-T L.1221 evaluates stationary telecom batteries against a defined application, including discharge-rate capability, life at a stated temperature, cycling conditions, end-of-life capacity, partial-charge behavior and environmental criteria. Its example values are explicitly application-dependent; they should not be copied into an RFQ as default Huijue ratings.

Path efficiency belongs to one boundary only. If E_{load} comes from a meter at the battery output and already includes downstream losses, set η_{path} accordingly rather than subtracting those losses twice. If the measurement is at the radio load, add the intervening cable, protection, DC/DC or inverter losses using evidence at the relevant operating point.

A worked four-hour telecom backup calculation

Consider a hypothetical grid-connected site; these are calculation assumptions, not a Huijue product rating. The critical load is 2.4 kW for the first 0.5 hour. A permitted auxiliary then sheds, leaving 1.8 kW for the remaining 3.5 hours.

Input	Illustrative value	Boundary
Outage load energy	(2.4 kW × 0.5 h) + (1.8 kW × 3.5 h) = 7.50 kWh	Energy at the declared critical-load boundary
Path efficiency	0.96	Illustrative battery-to-load efficiency
Usable SoC window	0.80	Approved start minus protected stop
Minimum-temperature factor	0.90	Illustrative factor to be replaced by product data

Input	Illustrative value	Boundary
End-of-life factor	0.80	Illustrative replacement criterion
Load uncertainty factor	1.10	Documented 10% design allowance

$E_{nominal,required} = (7.50\ kWh \times 1.10) \div (0.96 \times 0.80 \times 0.90 \times 0.80)$

$E_{nominal,required} = 14.92\ kWh$

The 14.92 kWh result is a nameplate-energy screen under the stated factor model. It is not permission to select the nearest catalog total. The candidate module count must still deliver at least 7.50 kWh to the load at the specified temperature, discharge duration, voltage cut-off and end-of-life condition, while satisfying current, BMS and redundancy requirements.

Sensitivity shows where evidence matters. With every other assumption unchanged, reducing the temperature factor from 0.90 to 0.80 raises the screen from 14.92 kWh to 16.79 kWh. Changing the end-of-life factor from 0.80 to 0.70 raises it to 17.05 kWh. Reducing the usable SoC window from 0.80 to 0.70 also gives 17.05 kWh. Those are arithmetic consequences, not recommended project factors.

Round only after matching the result to real module increments, parallel-unit limits, enclosure space and maintenance policy. If the service requirement includes one battery module unavailable, repeat the capacity and power checks with the largest permitted unit removed; adding one module after the calculation may not provide true one-unit-out coverage.

Can ampere-hours be converted directly into backup time?

Only as a rough screen when the voltage basis, discharge rate, temperature, end voltage and product rating conditions are known. Ampere-hours alone do not state how much energy reaches a constant-power telecom load over its full voltage range.

Screening energy (Wh) ≈ rated capacity (Ah) × appropriate average discharge voltage (V)

Battery current for a constant-power load $\approx P_{load} \div (V_{battery} \times \eta_{path})$

As battery voltage falls, a regulated constant-power load draws more current. A 2.4 kW load supplied at an illustrative 44 V through a 96% efficient path requires about 56.8 A from the battery. The calculation must verify that the battery, BMS, contactors, fuses or breakers, busbars, terminals and conductors can support that current at the end of discharge.

Lead-acid capacity varies materially with discharge rate and cut-off voltage, so use the supplier’s constant-power or discharge-rate tables rather than one Ah label. Lithium modules can maintain a flatter voltage for much of the discharge, yet the BMS may derate or disconnect on cell voltage, current, temperature or imbalance before a nameplate Ah calculation reaches zero. For both technologies, released product curves take precedence over a generic conversion.

Check power and voltage after the energy result

A battery can contain enough calculated energy and still fail the site during the first second or final minute. Check continuous and transient current, the lowest battery terminal voltage, distribution drop, load-input minimum, protective-device behavior and BMS limits across the duty.

Use the highest credible critical load for the power check, not the average energy load. Calculate current at the lowest approved operating voltage because that is where a constant-power load demands the most current. Then add the measured or calculated drop through each battery branch and the common DC distribution. The telecom DC distribution guide owns breaker, fuse, cable and disconnect coordination.

Confirm that low-voltage disconnect and BMS cut-off thresholds leave the connected equipment inside its permitted input window. A configuration that protects the battery by opening before the required energy is delivered does not meet the autonomy target. A configuration that reaches the radio’s undervoltage restart point before protection operates also fails, even if the battery still contains stored energy.

Capacity is incomplete without a recharge check

The recovery source must carry the live telecom load and return the required energy before the next credible outage. A larger battery increases recharge demand; it does not automatically improve readiness when rectifier or grid capacity is constrained.

$$P_{charge,available} = P_{source,usable} - P_{live} - P_{other,active}$$

$$\text{Screening recovery time} \approx E_{returned} \div P_{charge,to\ battery}$$

The actual time is longer when charging tapers, temperature or BMS limits reduce current, source power varies, or other loads take priority. Establish the required reserve-recovery time, then check the rectifier count, AC input limit, generator capability and battery charge-acceptance curve. The telecom rectifier guide covers module capacity and redundancy; the outage-sequence article defines when recovery begins and which loads return.

How should the calculated capacity be validated?

Validate the screen against traceable manufacturer discharge data and then test the approved configuration at defined conditions. The evidence should show delivered energy, minimum voltage, peak current, protection behavior and recharge performance for the actual module count and controller settings.

Validation step	Record	Decision
Load-model review	Meter intervals, inventory, outage states, load-shed schedule and growth basis	Does E_{load} represent the required service?
Product-data match	Constant-power or discharge curves at required duration, temperature and end voltage	Can the candidate deliver the calculated load energy under the same conditions?
Power-path check	Voltage window, current limits, cable drop, protection and one-unit-out case	Does the load remain inside its operating window throughout the duty?
Controlled discharge	Starting SoC, cell or module temperature, load, bus voltage, current, energy and alarms	Does measured autonomy meet the acceptance limit without unintended trip or restart?
Recovery test	Live load, source power, charge current, temperature, time and restored reserve	Can the site recover before the next design event?

Keep the calculation revision, product data, instrument records, configuration export and test results together. Recalculate when tenant load, radio configuration, cooling strategy, battery model, controller reserve or replacement criterion changes. State-of-charge and state-of-health estimates are useful operating inputs, but periodic evidence is still needed to confirm that installed capacity remains available.

Engineering boundary. The formula and worked example are screening tools. Final capacity requires the actual load profile, outage and load-shed sequence, battery product curves, minimum cell temperature, end-of-life criterion, DC voltage window, protection settings, redundancy requirement, recharge source and applicable operator or regulatory rules.

Submit one calculation boundary, not disconnected ratings

For a Huijue battery-capacity review, provide interval load data, the required outage sequence and autonomy, permitted load shedding, start and stop SoC, minimum cell temperature, end-of-life criterion, DC voltage window, source and rectifier limits, recovery target, planned growth and redundancy policy.

Send the battery-sizing inputs

Related engineering resources

Telecom Lithium Battery Systems
Grid-Outage Backup Sequence
Telecom Solar and Battery Sizing
Telecom Energy Products and Services

Contact Us

For catalog requests, pricing, or partnerships, please visit:
https://www.thesolartelecom.com

Telecom Battery Backup Time Calculation: Load, DoD, Temperature and Aging