HUIJUE GROUP



Types of Batteries Used in Telecom: LiFePO4, NMC and VRLA Compared

Compare LFP, NMC and VRLA batteries for telecom sites by duty, temperature, footprint, charging, maintenance, safety evidence and lifecycle cost.

PRODUCT KNOWLEDGE

Types of Batteries Used in Telecom: LiFePO4, NMC and VRLA Compared

Compare three established telecom battery choices against the same operating duty, site temperature, footprint, charging method, maintenance model and evidence standard.

Updated August 21, 2026Battery technology comparisonApprox. 12 minute read

Contents

Best fit by duty
Comparison matrix
LiFePO4
NMC
VRLA
Temperature
Fleet transition
Decision evidence

Put three sites beside one another: a cool exchange room with rare grid outages, a street cabinet where every rack unit matters, and a solar radio site that cycles its battery most days. Buying the same battery technology for all three may simplify one purchase order, but it can also transfer cost into cooling, replacement visits, unused capacity or operating risk.The useful comparison between **telecom battery types** is therefore not a contest between chemistry labels. Each candidate must be normalized to the energy delivered to the declared load, at the design temperature and end-of-life condition, while meeting the same power, recharge, safety and maintenance requirements.

> A chemistry should remain on the shortlist only when its complete battery system can perform the site’s duty. Cell-level energy density, cycle claims or purchase price cannot decide the project on their own.

Which battery type is best for a telecom site?

LiFePO4 is often the strongest starting candidate for stationary sites with repeated cycling, limited maintenance access or constrained cabinet space; VRLA can remain a rational choice for infrequent standby duty in a controlled environment with an established support fleet; NMC earns consideration when usable energy per unit of space or mass is a decisive constraint. None is an automatic winner without product-level data

and a site-specific duty statement.

That recommendation is a shortlist, not a released design. The battery still has to fit the site’s actual DC operating window, charge source, reserve policy, fault protection, enclosure environment and monitoring architecture. The telecom lithium battery system guide owns those broader integration decisions; this article stays with the technology comparison.

Use the following duty cues before looking at catalog capacity:

- For rare emergency discharge, emphasize calendar ageing, float or standby behavior, periodic capacity verification and the logistics of replacement.
- For weak-grid operation, emphasize repeated partial cycles, recharge opportunity, current limits, reserve recovery and time spent at low state of charge.
- For solar cycling, emphasize energy throughput, charge acceptance across temperature, usable depth of discharge, seasonal recovery and auxiliary heating or cooling.
- For rooftop, pole or street installations, include mass, rack volume, lifting method, structural loading and service clearances.
- For remote fleets, value alarm quality, state estimation, replaceable-unit strategy, spares storage and technician capability alongside battery price.

How do LiFePO4, NMC and VRLA differ at the site boundary?

LiFePO4 generally trades some lithium-ion energy density for stronger thermal stability, NMC generally prioritizes energy density with a tighter thermal-risk case, and VRLA offers mature float-service practice with greater mass and volume for a comparable delivered-energy target. Actual results depend on cell design, pack construction, operating window, temperature and the evidence supplied for the complete product.

ETSI TS 103 553-2 provides a telecom-specific method for evaluating batteries by defined application. Its informative chemistry discussion characterizes LFP as having good safety and thermal properties and NMC as having good energy density but lower stability than LFP; it also describes VRLA as mature and widely used. These family-level characteristics guide preselection, not acceptance of a particular module.

Decision criterion	LiFePO4	NMC	VRLA
Typical reason to shortlist	Repeated cycling, integrated monitoring, compact stationary storage and relative thermal stability within	High usable energy or power must fit a particularly tight mass or volume envelope	Mature standby practice, familiar float systems, established supply chain and lower initial battery cost in many markets

Decision criterion	LiFePO4	NMC	VRLA
	common lithium-ion choices		
Primary engineering caution	Product-specific BMS limits, low-temperature charging, voltage-window fit and parallel-unit policy	Thermal propagation controls, operating-window discipline and proof that pack-level density justifies added controls	Temperature exposure, footprint, repeated partial-state cycling, inspection depth and replacement logistics
Control model	Cell-level monitoring and protection are integral to the approved battery system	Cell-level monitoring and protection are integral to the approved battery system	Usually managed through charger settings, string or block monitoring and periodic service rather than lithium-style cell BMS control
Charge behavior to verify	Permitted current and voltage versus temperature, SoC and module state	Permitted current and voltage versus temperature, SoC and module state	Float, boost or equalization rules where applicable, temperature compensation and recharge duration
Best comparison evidence	Complete module curves, BMS actions, safety reports and cycling data at project conditions	Complete pack curves, propagation and protection evidence, thermal design and usable pack-level energy	IEC 60896 evidence where applicable, capacity and life data at temperature, float settings and maintenance records

Do not compare one supplier’s beginning-of-life cell watt-hours with another supplier’s end-of-life system output. Normalize usable energy after voltage cut-offs, temperature derating, ageing allowance, conversion losses and protected reserve. Then test whether the candidate can also supply the peak current and recover before the next credible outage.

When is LiFePO4 the strongest candidate?

LiFePO4 is a strong candidate when a telecom site combines regular cycling, limited rack space, remote monitoring needs and a preference for lithium chemistry with relatively favorable thermal stability. It is frequently shortlisted for weak-grid and solar-assisted sites, provided the exact module can meet the site’s temperature, voltage, current and recharge conditions.

An **LFP telecom battery** can package substantial usable energy into a 19-inch rack format and can tolerate partial-state operation better than conventional standby-oriented VRLA designs. Integrated BMS data can also make module voltage, current, temperature, state estimates and protective events visible to the operator. These benefits are valuable only when the site controller receives meaningful alarms and the local protection remains effective if communication is lost.

LFP does not mean “safe at any temperature” or “maintenance-free.” Charging may be restricted below a product-defined cell temperature; high temperature and high state of charge can still accelerate ageing; contactors, sensors, firmware and communication add failure modes; and poor propagation control or installation can defeat cell-level advantages. Request limits and test evidence for the exact cell, module, firmware and parallel arrangement.

The battery’s series-cell count and approved charge window must also fit the connected telecom equipment. A nominal voltage printed on a module does not establish the highest charge voltage, the lowest supported load voltage or the current near discharge cut-off. Use the telecom DC voltage-interface guide when checking that boundary.

When does NMC justify its place in a telecom design?

NMC deserves a detailed evaluation when the project cannot meet its usable-energy target with the available mass or volume using a lower-density option. Examples can include weight-limited rooftops, very compact access cabinets or replacement projects where civil and enclosure changes are disproportionately difficult.

A proposed **NMC telecom battery** should be compared at pack level, after allowing for enclosure, separation, cooling, fire-detection or suppression measures, protection electronics and service access. A higher cell energy density may deliver little project advantage if the complete installation requires substantially more supporting space or auxiliary load.

NMC is a family with changing nickel, manganese and cobalt proportions rather than one fixed material. Cell format, supplier process control, state-of-charge window, cooling, BMS thresholds and propagation design can change its behavior materially. The procurement record should identify the exact chemistry and cell model instead of accepting “lithium-ion” or “NMC” as sufficient traceability.

A project should not reject NMC through slogans, but it should demand a stronger explanation of why its density benefit is necessary and how the complete battery system manages thermal and electrical faults. If the same duty fits comfortably in an LFP or VRLA envelope, higher density alone may not justify a different safety, service and spares model.

When does VRLA still make engineering sense?

VRLA can remain suitable for infrequent standby service where temperature is controlled, floor or rack loading is acceptable, the rectifier plant is already designed for the battery, and the operator has established inspection, testing, replacement and recycling procedures. Its mature standards base and broad service familiarity can

reduce transition risk for some fleets.

A **VRLA telecom battery** may also be attractive when the immediate procurement budget is the dominant constraint and the site does not impose frequent deep cycling. The comparison must still include shorter replacement intervals under adverse heat, transport mass, technician visits, string imbalance, capacity testing and the value of floor or rack space. A low battery price is not necessarily a low cost per delivered service year.

IEC 60896-22:2004 covers requirements for stationary valve-regulated lead-acid cells and monobloc batteries used in float-charge telecom and similar standby applications, together with the test methods in IEC 60896-21. That scope is useful evidence for an applicable VRLA product, but it does not prove suitability for daily solar cycling or a hot outdoor cabinet.

VRLA is valve regulated, not hermetically sealed and not free from operating checks. The installation still needs the applicable ventilation and electrical safety assessment, correct charge settings and temperature compensation, accessible terminals, connection inspection, swelling or leakage checks, capacity verification and an end-of-life replacement plan. AGM, gel, pure-lead and cycling-oriented variants should not be treated as identical products.

Temperature can overturn the paper comparison

Compare technologies against cell temperature over time, not a single annual-mean ambient value. Solar gain, internal electrical losses, restricted airflow, cabinet color, insulation, heater operation, altitude and neighboring equipment can create a battery temperature profile that differs sharply from the weather file.

Heat can accelerate ageing across battery families, although the rate and failure mechanisms differ. Cold conditions can limit discharge power and make charging restrictions decisive for lithium systems. For VRLA, charger temperature compensation and hot-site life data matter; for lithium, the BMS charge and discharge limits, sensor placement and heater strategy must be explicit.

Temperature is a design input, not a footnote. Request capacity, power, charge-acceptance and life information at the expected cell-temperature range. Add heater or cooling energy to the site load model instead of treating thermal management as free.

A technology that needs active cooling to survive the site may increase PV, rectifier and battery capacity as well as maintenance exposure. Conversely, removing legacy air conditioning after changing batteries is valid only when the radio, transmission, power

electronics and every other cabinet component remain within their released conditions. The outdoor telecom cabinet guide explains that shared thermal boundary.

Changing chemistry changes the operating system

Replacing VRLA with lithium, LFP with NMC or one lithium platform with another is not a like-for-like module swap. The project must revalidate the DC interface, charge method, low-voltage disconnect, protection, fault contribution, cabling, thermal design, alarm mapping, spare strategy and safe work procedure.

1. Freeze the same time-based critical-load profile, autonomy, reserve and recovery requirement for every candidate.
2. Check maximum and minimum battery voltage against rectifiers, solar controllers, distribution devices and connected loads.
3. Compare continuous and transient current, branch protection, prospective fault current, terminals and cable limits.
4. Recalculate cabinet space, structural load, lifting access, ventilation, heating, cooling and auxiliary energy.
5. Define local protection, site-controller permissions, alarm semantics, communication-loss behavior and data retention.
6. Plan technician training, spares storage, module matching, transport, damaged-unit handling, recycling and end-of-life replacement.

For a fleet transition, pilot results should be measured against the former service rather than against dashboard availability alone. Record delivered energy, reserve recovery, temperature distribution, protective events, alarm usefulness, technician time and any changes to generator or cooling operation. A pilot cannot establish long-term life immediately, but it can expose interface and maintenance assumptions before wide deployment.

Evidence should decide the final shortlist

A defensible **battery chemistry comparison** uses one requirements sheet and asks each supplier to state compliance, deviation and evidence against the same conditions. The decision record should show why a technology was selected for this duty, not merely why another technology was rejected in general.

Request the exact cell and module identity; usable energy and power at project temperatures and voltage limits; charge restrictions and recovery time; applicable safety and performance reports; BMS or monitoring behavior; enclosure and thermal requirements; approved parallel and replacement rules; warranty conditions; service support; and transport, recycling and disposal documentation. Separate independently testable evidence from supplier projections and project assumptions.

Total cost should use a declared evaluation period and boundary. Include the battery system, cabinet or room changes, protection and monitoring, cooling or heating energy, installation, scheduled tests, expected replacements, spares, truck rolls, training and end-of-life handling. Sensitivity cases are more honest than a single lifetime claim when temperature, outage frequency or future load remains uncertain.

Compare all candidates on one site duty

Provide Huijue with the load profile, autonomy and reserve, outage and cycling pattern, recharge sources, DC voltage limits, site temperature range, cabinet or room constraints, monitoring requirements, destination market and fleet maintenance model. Huijue can then prepare a project-specific LFP, NMC or VRLA shortlist without treating one chemistry as a universal default.

Submit the battery comparison inputs

Related engineering resources

Telecom Lithium Battery Systems
Telecom Solar and Battery Sizing
Outdoor Telecom Cabinet Guide
Telecom Energy Standards Map

Contact Us

For catalog requests, pricing, or partnerships, please visit: https://www.thesolartelecom.com



Types of Batteries Used in Telecom: LiFePO4, NMC and VRLA Compared